



GLOBAL REFINISH
SYSTEM

Product Information

D894 High Solids Clear (California)

Product Description

D894 High Solids Clear is a premium quality high solids clearcoat specifically formulated to give optimum gloss and durability.

D894 is designed for use over Global BC Colour (see Data Sheet EU02).

Preparation of Substrate



In all cases, wash all surfaces to be painted with soap and water, then apply the appropriate Global cleaner. See GLG-142 Global Cleaners bulletin for selection and usage instructions. Ensure that the substrate is thoroughly cleaned and dried both before and after application work.



Wet sand with European P800-1200 / U.S. 500-600 grade paper or dry sanding with European P600-800 / U.S. 400-500 grade paper.



Wash off residue and dry thoroughly before recleaning with appropriate Global substrate cleaner. The use of a tack rag is recommended.

Apply Global BC Colour over original stoved finishes or over recommended Global Primers. See Data Sheet EU02 for Global BC system application details.

APPLICATION GUIDE

Overcoat / Recoat:



Overcoat/Recoat Time

6 – 8 hours @ 20°C / 68°F or after force dry/cool down



Grade wet

European P800 – 1200 / U.S. 500 – 600

Grade dry

European P600 – 800 / U.S. 400 – 500



Overcoat with

Any Global topcoat system

Performance Guidelines:

Allow the Global BC Colour to flash off for 15 minutes (but no longer than 24 hours) before applying D894 Clear. The timing will depend on thickness and temperature.

Recoating times will be extended at lower temperatures. Global D894 may be sanded with 1200 grit paper or finer and polished when hard, to rectify minor imperfections.

Fading Out - D894 Clear After spot repairing, clean the gun and then spray Global Blending Thinner D853 around the repaired area to lose the edge and blend the repair into the surrounding panel. Spray starting from the outside of the repair, moving to the center.

Technical Data:

Total dry film build

Minimum	50µm / 2.0 mils
Maximum	75µm / 3.0 mils
Recommended film build per wet coat	40 – 75µm / 2.4 – 3.0 mils
Recommended dried film build per coat	25 – 31µm / 1.0 – 1.25 mils

Theoretical coverage 16.45 m² per litre / 669.51 sq. ft. per US gal.

Note: Theoretical coverage in m²/litre and sq.ft./US gal. Ready-to-spray (RTS), giving 25 µm (1 mils) dry film thickness.

Percent solids by volume RTS 43.3

VOC

(D894)	483.6 gms per litre / 4.03 lbs. per US gal.
(D894:D887:D872, 3:1:1)	405.6 gms per litre / 3.38 lbs. per US gal.

Product Compatibility:

D894 may be applied over any Global basecoat

Health and Safety:



See Material Safety Data Sheet and Labels for additional safety information and handling instructions.



- The contents of this package may have to be blended with other components before the product can be used. Before opening the packages, be sure you understand the warning messages on the labels and MSDS's of all the components, since the mixture will have the hazards of all its parts.



- Improper handling and use, for example, poor spray technique, inadequate engineering controls and/or lack of proper Personal Protective Equipment (PPE), may result in hazardous conditions or injury.
- Follow spray equipment manufacturer's instructions to prevent personal injury or fire.
- Provide adequate ventilation for health and fire hazard control.
- Follow company policy, product MSDS and respirator manufacturer's recommendations for selection and proper use of respiratory protection. Be sure employees are adequately trained on the safe use of respirators per company and regulatory requirements.
- Wear appropriate PPE such as eye and skin protection. In the event of injury, see first aid procedures on MSDS.
- Always observe all applicable precautions and follow good safety and hygiene practices.

High Solids Clear

Mix:



D894	3 vols
Hardener	1 vol
D-Thinner	1 vol

Hardener Selection

D884	Air Dry / General Purpose
D887	Stoving / Mar Resistance

Thinner Selection

D8764	Fast Compliant Thinner
D8767	Compliant Thinner
D8774	Medium Compliant Thinner

Note: Smaller areas may require faster thinner.

Additives:



Use D885 Enhancer for enhanced cure	Add 1/2 fl. oz. per ready to-spray U.S. quart.
Use D886 Extender to extend cure	Add 1/2 fl. oz. per ready to-spray U.S. quart.
Use D759 Matting Base to flatten D894 Clear	See EU-33 for application instructions.
Use D814 Plasticiser to flexibilize D894 Clear	See EU-47 for application instructions.

Pot life:



@ 20°C / 68°F	5 – 6 hours
---------------	-------------

Air Pressure:



HVLP:	0.7 bar / 10 PSI at the air cap
Conventional:	3 – 4 bar / 45 – 55 PSI
Fluid tip:	1.3 – 1.5 mm or equivalent

Application:



Apply:	2 normal coats
Between coats	5 – 10 minutes
Before stoving	0 – 15 minutes
Film build per wet coat	2.4 – 3.0 mils
Dried film build per coat	1.0 – 1.25 mils

Dry times:



Dust-free 20°C / 68°F	30 – 45 minutes
Dry to handle	
20°C / 68°F	3 – 4 hours
60°C / 140°F	30 minutes



Tape Time	
20°C / 68°F	7 – 8 hours
60°C / 140°F	30 minutes



Through Dry	
20°C / 68°F	8 hours
60°C / 140°F	30 minutes



IR (infrared)	
Medium Wave	15 minutes
Short Wave	8 minutes



Dry to Topcoat	
20°C / 68°F	6 – 8 hours or after force dry/cool down
60°C / 140°F	

Note: All force dry times are quoted for metal temperature. Additional time must be allowed during force dry to allow metal to reach recommended temperature.

Emergency Medical or Spill Control Information (304) 843-1300; In Canada (514) 645-1320

Materials described are designed for application by professional, trained personnel using proper equipment and are not intended for sale to the general public. Products mentioned may be hazardous and should only be used according to directions, while observing precautions and warning statements listed on label. Statements and methods described are based upon the best information and practices known to PPG Industries. Procedures for applications mentioned are suggestions only and are not to be construed as representations or warranties as to performance, results, or fitness for any intended use, nor does PPG Industries warrant freedom from patent infringement in the use of any formula or process set forth herein.

**PPG Industries
19699 Progress Drive
Strongsville, OH 44149**

**PPG Canada Inc.
1330 Castlefield Avenue
Toronto, Ontario M6B 4B3**